

Advantage of this solution

- > Support standalone, or being integrated to any type of MDVR flexibly.
- > Voice of outer speaker can be adjusted in different time period. Don't disturb the living of inhabitants.
- > Content of alarm of outer speaker can be customized. Multiple languages supported.

BSD1-Fisheye image



BSD2-Normal AHD image



BSD demo Link

<https://www.youtube.com/watch?v=O9obNFnCvz4>

BSD

Intelligently detect **pedestrian, cyclist, motorcyclist, person with umbrella** etc. moving subject in the blind zone. Different warning level to different zone. With Front, left corner, right Corner option.

"Alarm on threshold"	Not valid for now, BSD is enabled by default below 30km/h
"Upper left coordinate"	Locate the upper left corner of the alarm frame, and press the up, down, left, and right arrows to adjust the position of the calibration frame
"lower left corner coordinates"	Locate the lower left corner of the alarm frame, and press the up, down, left, and right arrows to adjust the position of the calibration frame
"Upper right coordinate"	Locate the upper right corner of the alarm frame, and press the up, down, left, and right arrows to adjust the position of the calibration frame
"lower right corner coordinates"	Locate the lower left corner of the alarm frame, and press the up, down, left, and right arrows to adjust the position of the calibration frame
"left BSD setting"	The calibration frame of the left blind spot is preset, and the calibration frame can be quickly set, and then it is associated with the blind spot attribute after setting.
"Right BSD setting"	The calibration frame of the right blind spot is preset, and the calibration frame can be quickly set, and then it is associated with the blind spot attribute after setting.
"Front BSD setting"	The calibration frame of the front blind spot is preset, and the calibration frame can be quickly set, and then it is associated with the blind spot attribute after setting.

BSD System and Installation Instruction



